



CYRUS





IMPORTANT! Read before operating this equipment!

CAUTION: The exclamation mark is to draw your attention to important instructions and safety procedures in this manual.



ATTENTION: The lightning flash warns you of the risk of electrical shock presented by components inside this product. Unauthorised personnel must not open this unit.



WARNING: To reduce the risk of electrical shock do not remove any unit covers or panels. There are no user serviceable parts in this product.

WARNING: To reduce the risk of electric shock, do not expose this equipment to rain or moisture.

HEED WARNINGS: All warnings on the product and in the operating instructions should be adhered to.

READ ALL THE INSTRUCTIONS: All the safety and operating instructions should be read before the product is operated.

RETAIN INSTRUCTIONS: The safety and operating instructions should be retained for future reference.

FOLLOW INSTRUCTIONS: All operating and use instructions should be followed.

CLEANING: Unplug this product from the mains before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.

WATER AND MOISTURE: Do not use this product near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement; or near a swimming pool and the like. The product must not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the product.

HEAT: The product should be situated away from heat sources such as radiators, stoves, or any other products (including amplifiers) that produce heat.

VENTILATION: Slots and openings in the cabinet are provided for ventilation, to ensure reliable operation of the product and to protect it from overheating and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug or similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

OBJECT OR LIQUID ENTRY: Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock.

ACCESSORIES: Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

ATTACHMENTS: Do not use attachments not recommended by the product manufacturer as they may cause hazards.

MOVING THE PRODUCT: A product and cart combination should be moved with care. Sudden stops, excessive force, and uneven surfaces may cause the product and cart to overturn.



POWER SOURCES: This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

OVERLOADING: Never overload wall outlets, extension cords, or integral convenience receptacles. This can result in an increased risk of fire or electric shock.

POWER CORD PROTECTION: Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

NAKED FLAMES: No naked flame sources, such as candles, must be placed on this product.

LIGHTNING: For added protection for this product during a lightning storm, or when it is left unattended or unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

CAUTION! POLARISED CONNECTOR (CANADA and USA):

To prevent electrical shock, match wide blade of plug to wide slot, fully insert. Do not alter or remove this plug if it does not fit your mains power socket. Have a suitable socket installed by a competent electrician.

POWER SUPPLY:

Connect the moulded IEC connector of the AC cord supplied into the power inlet ③ on the rear of the unit. The mains fuse ② is on the rear panel next to the power switch. It must only be replaced as follows:

U.K. / Europe 230V	T2AL/250V 20mm
N. America 115V	T2.5AL/250V 20mm

The mains supply requirement for your *Cyrus PSX-R* is marked on a label on the rear panel. Before connecting, check that this voltage is the same as your mains supply.

230V Products:	Voltage Range	220V-240V
115V Products:	Voltage Range	110V-120V

If you move to an area with a different mains voltage, contact your local *Cyrus* distributor to have your product converted.

SERVICING:

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

CONDITIONS REQUIRING SERVICE: Unplug this product from the wall outlet and refer servicing to qualified service personnel when:

- When the power supply cord or plug is damaged.
- If liquid has been spilled, or objects have fallen into the product.
- If the product has been exposed to rain or water.
- If the product has been dropped or damaged in any way.
- If the product does not operate normally by following the operating instructions. (Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage requiring extensive work by a qualified technician to restore the product to its normal operation).
- When the product exhibits a distinct change in performance.

REPLACEMENT PARTS: When replacement parts are required, be sure the service technician has used replacements specified by the manufacturer or have the same characteristics as the original part. Unauthorised substitutions may result in fire, electric shock, or other hazards.

SAFETY CHECK: Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

PRODUCT SERVICE CENTRES

For product service or technical advice, contact only authorised *Cyrus* service centres. Contact details for *Cyrus* distributors may be found on the *Cyrus* website at www.cyrusaudio.com.

Welcome to the world of *Cyrus!*

Congratulations on your choice of *Cyrus* Hi-fi products. Our state-of-the-art design technology and outstanding quality of manufacture has won countless awards around the world. We are confident that you will derive great pleasure from owning a product from one of the most recognised and respected manufacturers of hi-fi equipment.

Now is a good time to register your new *Cyrus* product. Registration takes only a few minutes, brings the added benefit of a full two year factory warranty and adds you to our mailing list for future product updates and upgrades. To register, visit www.cyrusaudio.com and click the 'Login/Register' link.

Please read these instructions carefully before commencing installation. They provide full guidance to help you install your *PSX-R* safely and correctly.

Preparation for Installation

Before installing the *Cyrus PSX-R* check that the following item is included in the accessory box.

- AC Mains Cable

After removing this, please retain the packaging.

Install the *Cyrus PSX-R* in a well ventilated location away from sources of high temperature, dust or humidity. Never stand the *Cyrus PSX-R* under another unit or on any surface likely to hamper its cooling or ventilation.

INSTALLATION

Key to the rear panel drawing (*Fig. 1*).

1. Power Switch
2. Mains Fuse
3. Power Inlet
4. Output cable

Connecting the PSX-R to *Cyrus* Products

Only one connection is necessary from the *PSX-R* power supply to a *Cyrus* product. The 5 pin connector ④ fitted to the umbilical cable must be securely connected to the socket marked *PSX-R* on the rear of the partnering *Cyrus* product. When correctly fitted, the connector will latch into place in the socket. Note that when a *PSX-R* is in use, both the *PSX-R* power supply and the *Cyrus* product will require connection to the mains supply.

NOTE: When used with a *Cyrus III*, *Cyrus IIIi*, *Cyrus 7* or *Cyrus Power*, the amplifier must be internally changed to accept this external power supply. This modification should only be carried out by an appointed *Cyrus Dealer*. If you decide to use a modified component without a *Cyrus PSX-R*, the unit must be re-configured.

OPERATION

Key to the front panel drawing (*Fig 2*).

1. Standby Light

Power

The mains power switch ① is located on the rear panel of the power supply. This switch should be left on for normal use, except when left unattended for a long period. In this case the mains power should be switched off or the product disconnected from the AC supply.

In normal use, Standby operation of the *PSX-R* is controlled by the partnering *Cyrus* component. When correctly installed, the Standby lights on the front panels of the two products work in unison.

ADDITIONAL INFORMATION

Your *Cyrus PSX-R* incorporates electronic protection to ensure reliable, long term use. The *Cyrus PSX-R* is designed to adjust its output DC voltage to that required by the partnering *Cyrus* product.

Two levels of regulation exist in the *PSX-R* circuitry in order to give maximum isolation from mains borne disturbances and the voltage ripple due to the charging of the supply reservoir capacitors, this design has also enhanced the load-regulation of the *PSX-R*.

WARRANTY

The warranty should be registered on-line within 8 days of purchase. No Dealer or Distributor may vary the terms of this warranty, which is personal to the original Purchaser and is not transferable.

Please retain the sales receipt as proof of purchase.

Warranty claims must wherever possible be made through the Dealer from whom the equipment was purchased.

This warranty excludes:

- Damage caused through neglect, accident, misuse, wear and tear, or through incorrect installation, adjustment or repair by unauthorised personnel. Any unauthorised servicing will result in loss of guarantee.
- Liability for damage or loss occurring in transit to or from the purchaser.
- Consequential damage, loss or injury, arising from or in conjunction with this equipment.

Equipment for attention under warranty should be consigned return carriage paid. If returned equipment is found to comply with the published specification, *CYRUS* reserves the right to raise a charge.

The above conditions do not affect your statutory rights as a consumer.

SPECIFICATIONS

Power Supply

Voltage:As plate on rear of unit

Power Consumption (*X Power*)

50W/8Ω 227W

EMC & Safety Compliance (230V) CE

Enclosure

Dimensions (WxHxD) 215 x 75 x 365mm

Weight 4.6kg

Material Die cast chassis

Output Voltage

High Level +/- 35.5VDC

Low Level +/- 21VDC

Variable +/- 18-30VDC

Load Regulation

Amplifier, 50W/Ch. 8Ω 1kHz 0.2%

O/P Noise

@250W <40μV

Ripple Rejection

@250W >67dB

Cyrus reserves the right to change all specifications without notice. E &OE

WEEE

This logo means that this product is not to be disposed of with your household waste. This product should be handed over to a designated collection point to be recycled. Your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information on collection points, contact your disposal service or City Hall.





Cyrus Audio Ltd., Ermine Business Park, Huntingdon, PE29 6XY, U.K.